


New!



EV30 HIKER PRO



- Hiker Pro is the upgrade electric vacuum cleaner of Hiker that can be handheld with a long telescopic handle.
- Press the button and start working.
- No need to use hose and electrical cords, it is driven by rechargeable battery and designed for all kinds of pools from large pools to small spas and hot tubs.
- Hiker Pro is equipped with a removable brush head that can scrub floor, wall and corner of the pool.



- Le Hiker Pro est un aspirateur électrique à main équipé d'un manche télescopique.
- Sans tuyau, ni câble, il est alimenté par batterie et est conçu pour les spas et piscines de toutes tailles.
- Les brosses de la tête d'aspiration permettent de décoller et récupérer facilement les salissures.
- La tête d'aspiration est démontable.

► Main Features Caractéristiques



Simple structure
Structure simple



Easy button
Interrupteur facile



Large suction door
and scrubbing brushes
Une entrée d'eau de grande
aspiration et des brosses



Large container
and removable brush head
Grande capacité de rétention et tête
d'aspiration démontable



Telescopic handle
Manche télescopique

Specifications

Voltage
Power
Battery capacity
Battery life
Charging time
Flow rate
Container capacity

Données techniques

Voltage 12.6V
Puissance 30W
Capacité batterie 2500mAh
Autonomie 60min
Temps de recharge 3-4h
Débit pompe 39L/min
Capacité de rétention 0.8L